



Skidoo XP Tunnel / Running Board Reinforcement Kit

You will need a 3/16" drill bit, electric drill and a rivet gun for installation.

1. Position left side brace onto footrest. The brace will only fit in one position.



2. Make sure the brace fits in against the indentations in the running board and not on top as shown in the picture above.
3. Use a 3/16" drill bit and drill the three outer most holes using the brace as a template. Install the three rivets on the outer edge making sure the brace is pushed down tight against the running board.
4. Drill the six other holes in the running board and install the rivets making sure the brace is pushed down tight against the running board.
5. Drill the bottom three holes in the vertical part of the brace that is against the tunnel. Install these rivets.
6. Drill the top four holes at the top of the brace and install these rivets.
7. Repeat the same procedure for the right hand brace.

Grip N Rip Racing
234 Academy Rd
Monmouth, ME 04259
1-207-933-6279

www.gripnripracing.com

Email gripnripracing@roadrunner.com